# User Manual

## itoh Configurator
## for
## EtherNet/IP and PROFINET

Revision 02

February 22nd, 2019

Itoh Denki CO., Ltd.



English version
Translated on March 26th, 2019
Revision 02 - 001

Thank you for using ITOH DENKI products.

Use this product only after carefully reading this manual with full understanding of the content.

# WARNING and CAUTION

**WARNING** : must follow the user manual instruction otherwise resulting damaged to the equipment.

**CAUTION** : Possible safety hazard exist.

ⓘ : Information, must pay attention to notice given.

## ⚠ WARNING

Must comply to warning sign failure to comply will cause damage to the equipment and/or heavy injury of death.

## ⚠ CAUTION

Must comply to caution sign, failure to comply can result in damage to the equipment and injury or possible death

## DISCLAIMER;

- Prerequisite to use this manual properly, must have basic knowledge in electricity, computing, PLC and network communication.
- Figures, Numerical result and screen examples are only to assist the explanation and not to guarantee the result as shown.
- Itoh Denki cannot be held liable for any damages caused user or third party when,
  - Damage caused by improper use of this product.
  - Damaged caused by the product used in conjunction with third party products.
  - Damage caused by tampering and/or modification to the product.
  - Any damaged not caused by this product.
- Any concerns and questions please contact Itoh Denki.

## Table of contents

### Chapter 1 Introduction

1 General Description ..... 1-2
2 Platform Requirement ..... 1-2
3 Definition and Abbreviation ..... 1-3
4 Precautions ..... 1-4

### Chapter 2 Initial Settings

1 Home Screen ..... 2-2
2 Creating/Reading Projects ..... 2-5
3 Register/Delete IB Controller ..... 2-7
3.1 Register Duplicate IB Contoroller ..... 2-10
3.2 Node Comment Functions ..... 2-10
3.3 Delete Network ..... 2-11
3.4 Change Network Address ..... 2-11
4 Register/Delete Logic ..... 2-12
4.1 Import Logic ..... 2-14

### Chapter 3 Setting Properties

1 Setting Properties –Main Menu ..... 3-2
2 Motor Settings ..... 3-4
3 Error/Network Settings ..... 3-7
3.1 Auto/Host Error Release ..... 3-7
3.2 Inter-controller Communication Settings ..... 3-8
3.2.1 Auto IP Settings ..... 3-10
4 Acceleration/Deceleration ..... 3-11
5 Timer Settings ..... 3-12
6 Counter Settings ..... 3-13
7 Pulse Counter Settings ..... 3-14
8 Master/Slave Settings ..... 3-15
9 All Download or Upload ..... 3-16
10 Import and Export Property Settings ..... 3-17

## Table of contents

### Chapter 4 Create Ladder Logic


1 Logic Main Screen ..... 4-2
2 Selecting Command Input Mode ..... 4-2
2.1 Command Input (Advance Mode) ..... 4-3
2.2 Command Input (Basic Mode) ..... 4-4
2.2.1 How to Input Command ..... 4-5
3 Right Click Menu for Creating Logic ..... 4-6
3.1 Device List ..... 4-7


### Chapter 5 Command


1 Command ..... 5-2
1.1 Bit / JMP / RST ..... 5-2
1.2 FB (Action) ..... 5-8
1.3 FB (Compare) ..... 5-25
1.4Command List ..... 5-26
2 Contact List ..... 5-30
2.1 X Contact ..... 5-30
2.2 Y Contact ..... 5-33
2.3 D Register ..... 5-36
2.4 S Contact ..... 5-36
2.5 Other Contact ..... 5-37


### Chapter 6 Monitor Function


1 Logic Monitor ..... 6-2
1.1 Right Click Menu in Logic Monitor ..... 6-3
1.2 Force ON/Force OFF ..... 6-3
2 Error Information ..... 6-4
2.1 Error History ..... 6-5
3 Speed / Current Monitor ..... 6-6

## Table of contents

### Chapter 7 LD Recorder


1 Home Screen ..... 7-2
2 Menu Bar ..... 7-2
2.1 File ..... 7-3
2.2 Log ..... 7-3
2.2.1 Specify Folder to Save ..... 7-4
2.3 Monitor ..... 7-4
2.4 Setting ..... 7-5
2.5 Help ..... 7-6
3 Right Click Menu at Logic Screen ..... 7-7
3.1 Ladder Update ..... 7-7
3.2 Node Setting (IP Address Setting) ..... 7-7
3.3 Search ..... 7-7
4 How to Record the Log ..... 7-8
4.1 Logging (Manual) ..... 7-9
4.2 Logging (Trigger) ..... 7-12
5 Log Search ..... 7-14
5.1 Log Search Result Color Code Legend ..... 7-15
5.2 Narrow IP Address of Log ..... 7-16
5.3 Upload Log ..... 7-17
5.4 Comment Input ..... 7-18


### Chapter 8 Maintenance


1 Mechanical Test (Motor status monitor) ..... 8-2
2 Firmware Update ..... 8-3

## Table of contents

### Chapter 9 Other Functions


1 File ····· 9-2
1.1 Creating New Projects ····· 9-2
1.2 Print Preview ····· 9-3
2 Edit ····· 9-4
2.1 Find / Replace ····· 9-5
3 View ····· 9-6
3.1 Color Edit ····· 9-7
4 Build ····· 9-8
5 Network ····· 9-10
5.1 Network Message ····· 9-10
6 Dialog ····· 9-11
6.1 Discovery ····· 9-12
6.2 Information ····· 9-14
6.3 Jog Control (Jog operation) ····· 9-15
6.4 Auto Download. ····· 9-16
7 Online ····· 9-17
7.1 LD Recorder ····· 9-17
8 Option ····· 9-18
8.1 Unit ····· 9-18
8.2 Timeout Setting ····· 9-19
9 About ····· 9-19
9.1 Language Setting ····· 9-20
9.2 Help ····· 9-20
9.3 Version ····· 9-20


### Chapter 10 Troubleshooting


1 Troubleshooting for Property Setting ····· 10-2
2 Troubleshooting for Creating Logic ····· 10-3
3 Troubleshooting for Using Other Functions. ····· 10-5